



# SPEED-LINK WIRELESS INTERCOM USER GUIDE

# Table of Contents

---

<b>Button Overview</b>	<b>3</b>
<b>Powering On/Off</b>	<b>4</b>
<b>Charging</b>	<b>4</b>
<b>Language Choice</b>	<b>5</b>
<b>Connecting Microphone:</b>	<b>5</b>
<b>Connecting Helmet Speakers &amp; Earbuds:</b>	<b>5</b>
<b>Volume Up/Down:</b>	<b>5</b>
<b>Bluetooth Phone Pairing:</b>	<b>5</b>
<b>Play/Pausing Music:</b>	<b>5</b>
<b>Toggle Next/Previous Song:</b>	<b>6</b>
<b>Answering Phone Calls:</b>	<b>6</b>
<b>Voice Assistant:</b>	<b>6</b>
<b>Pairing Speed-Link to Speed-Link:</b>	<b>6</b>
<b>Group Pairing (Best for Long Range Connectivity)</b>	<b>6</b>
<b>Bluetooth Interconnection Mode:</b>	<b>7</b>

# Button Overview



# Getting Started

---

## Powering On/Off

Turn ON/OFF by pressing the Intercom Pairing and Multifunction button Simultaneously.

## Charging

To Charge Speed-Link. Simply plug the included USB-C cable into the USB-C port on the bottom of the unit. (NOTE: PLEASE USE INCLUDED USB-C cable)

## Language Choice

To select between languages, press the volume increase button and the multifunction button simultaneously.

## Connecting Microphone:

If your Speed-Link kit doesn't come with a pre-attached microphone or audio jack, locate the two female ports on the Speed-Link Harness. Choose the longest pair of wires. Plug in the red and white leads on the microphone into the microphone ports (NOTE: BE SURE TO SECURE MICROPHONE CONNECTION WITH HEAT SHRINK WRAP)

## Connecting Helmet Speakers & Earbuds:

Locate the 3.5mm audio jack and simply plug in Earbuds or a Helmet Speaker kit.

*\*If your Speed-Link harness does not include a mono 3.5mm jack. Choose the shortest pair of wires coming off of the harness/bracket. Wire a Mono Female 3.5 Audio Jack for optimal performance.\**

### **Volume Up/Down:**

Hold the Up and Down buttons on the front of the unit to change the volume.  
(You will hear a tone indicating volume level)

### **Bluetooth Phone Pairing:**

Hold the MODE and multifunction buttons at the same time. Hold down Until you see a red and blue flashing.

### **Play/Pausing Music:**

Click the Multifunction Button to toggle music.

### **Toggle Next/Previous Song:**

Click the Up / Down buttons to toggle Next/ Previous song in cue.

### **Answering Phone Calls:**

Press the Multifunction Button to answer a call. Press once again to end the call.

### **Voice Assistant:**

Press and hold the multifunction button until you hear a tone. This means that your voice assistant is activated.

## Pairing Speed-Link to Speed-Link:

Press the mode button to scroll through the options You are listening for “Bluetooth intercom mode”

Press and hold the mode button for approximately 4 sec

Bluetooth intercom light will Flash Quickly and you will hear a tone

Once green, press the Bluetooth intercom button to search and pair.

To disconnect, press the Bluetooth intercom button.

## Group Pairing *(Best for Long Range Connectivity)*

Cycle the MODE button until you hear “Bluetooth group intercom mode”

Press the Intercom Pairing button.

**Repeat these steps on up to six devices to connect**

## Bluetooth Interconnection Mode:

Cycle the MODE button until you hear “Bluetooth Interconnection”

Your device is now ready to pair with other 3rd party intercoms.